QUICKSTART Puzzi 100/200



Warning

These are only brief instructions! Please read and comply with these instructions prior to using or servicing your appliance.

The non-compliance of the operating and safety instructions may lead to damages of the appliance and to dangers for the operator and other persons.

Start up







- Insert the coupling of the fresh water hose Α into the fresh water connection of the a ppliance and lock into place.
- В Insert the suction hose into the suction hose connection on the appliance.



- В
- A Connect the fresh water hose to the elbow of the floor nozzle.
 - Connect the suction hose to the elbow В of the floor nozzle.


Operation








- Remove the lid. Α
- Remove the wastewater container from the appliance.
- Refill the wastewater container with fresh water.








- Fill in fresh water. Α
- Fill detergent solution/the tab including В its water soluble packaging into the fresh water reservoir. The fill level must not exceed the "MAX" mark. After 5 minutes, the tab will be completely dissolved.
- Insert dirt water reservoir into the appliance С and attach lid.
- A Press the spray switch to turn on the detergent pump.
- Press the suction switch to turn on the В suction turbine.
- C If the dirt water reservoir is full, switch off the suction and spray switches.

5.964-186.0 04/12

QUICKSTART



Operation






В

- A Use the lever on the bender to spray on detergent solution.
- Spray and suction off detergent solution in В one work cycle.
- A Highly soiled spots should be presoaked and the detergent solution should soak 5 to 10 minutes.
- B Vacuum up the detergent solution in the course of the second work step.

Finish operation








- Switch off the vacuuming and spraying Α switches.
- Remove the lid. В
- С Empty the wastewater reservoir.

5





- Fill the fresh water tank with clear water Α and to rinse/clean the appliance.
- Spray the accessories into the wastewater В tank, along with fresh water (approx. 1-2 minutes)
- C Empty the fresh water reservoir and switch the appliance off.
- D Empty the wastewater reservoir.



- A Place the lid loosely to let the appliance dry out.
- B For transport, place suction pipe on the carrying handle and place the spray/suction

hose on top of the appliance.

5.964-186.0 04/12